





















































# ATLANTA

趾盞く鋒但く暴猷箒整蚕

## BWS 113

### 4100-001-12.93

Abteilung	TB
Änd. Index	C / Wes.
Datum	1.1.2017

### 98 捌英鞞榭嬋減速器

Seite	24	24
Name	Behrens	30.05.08
freigegeben	Lorch	03.06.08

### Disposal



Please observe the national regulations!

If required, dispose of the individual components separately depending on their nature and any existing specific national regulations, e.g as:

- Steel scrap
  - gearwheels
  - shafts (hollow shafts)
  - antifriction bearings
  - cast iron parts
  - couplings
- Aluminium scrap
  - housing elements
  - adaptor elements
- Bronze scrap
  - worm-wheel (separated from hollow shaft)
- Collect waste oil and dispose of as directed

**ATLANTA does not accept liability for any damage to the transmission or any consequential damage, if these instructions are not observed.**